



# BRASS LIFT ROD DRAIN Instruction Sheet

DESAGÜE DE VARILLA DE ELEVACIÓN DE LATÓN Hoja de instrucciones

## INSTALLATION INSTRUCTIONS

1. Remove lift rod (**H**) and clip (**J**) from the inside of pop-up body (**B**)
2. Apply plumbers putty for seal under the flange (**A**)
3. Thread pop-up body (**B**) with rubber washer (**C**), friction washer (**E**) and nut (**D**) through sink hole into flange (**A**) then tighten to flange (**A**)
4. Insert lift rod (**F**) through faucet and attach extension strap (**G**). Tighten nut (**G**)
5. Insert pivot rod (**H**) into pop-up body (**B**) and through hole at bottom of pop-up (**K**), then hand-tighten nut (**I**). **DO NOT USE A TOOL** – Could result in over tightening and product failure.
6. Attach pivot rod (**H**) to extension strap (**G**) with clip (**J**)
7. Tighten all nuts
8. Cut tailpiece (**L**) to desired length. Apply pipe thread sealant to threads of tailpiece (**L**), and thread into pop-up body (**B**)
9. Attach drain to tailpiece (**E**). **CHECK FOR LEAKS**

## INSTRUCCIONES DE INSTALACIÓN

1. Quita la varilla de elevación (**H**) y el sujetador (**J**) del interior de la unidad emergente (**B**).
2. Coloca masilla de plomero para el sellado debajo de la brida (**A**)
3. Enrosca la unidad emergente (**B**) con la arandela de caucho (**C**), la arandela de fricción (**E**) y la tuerca (**D**) a través del orificio del fregadero y en la brida (**A**) y luego apriétalo a la brida (**A**)
4. Inserta la varilla de elevación (**F**) a través del grifo y fija la correa de extensión (**G**). Aprieta la tuerca (**G**)
5. Inserta la varilla pivotante (**H**) en la unidad emergente (**B**) y a través del orificio en su parte inferior (**K**) enseguida aprieta la tuerca (**I**) con la mano. **NO USAR HERRAMIENTAS** – Esto pudiera provocar que se apriete en exceso y el producto falle.
6. Fija la varilla pivotante (**H**) a la correa de extensión (**G**) con el sujetador (**J**)
7. Aprieta todas las tuercas
8. Corta el tubo de conexión (**L**) al largo deseado. Coloca sellador para roscas de tuberías en las roscas del tubo de conexión (**L**) e insértalo en la unidad emergente (**B**)
9. Conecta el desagüe y el tubo de conexión (**E**). **VERIFICA QUE NO HAYA FILTRACIONES**

